- Section 3.0 - Network functions and operations
- Section 4.0 - Host system operations and installations
- Section 5.0 - ViewStation Developer’s Kit
- Section 6.0 - HDS Warranty and Services
- Index

Section numbers are used throughout for organization and ease of reference.

Preface

This *HDS ViewStation System Administrator's Guide* is intended for advanced users, generally system administrators or individuals who have need to configure or customize ViewStations on a network.

This manual is intended as a reference point for ViewStation operations. There are many levels of functions in a distributed network environment, including the ViewStation and its server software or clients, the network itself, the host's operating system and utilities, the X protocol, and the application software you're running. Problems or configurations can occur at any level. This manual only addresses ViewStation issues and briefly describes some network and host system issues that are appropriate. More detailed information is available in other reference materials or manual pages for specific functions.

Additional material is available on the HDS Internet Server at:

http://www.hds.com

A hypertext version of this manual is available on the HDS Internet site.

This manual is shipped with the HDSware distribution. It is also available to users as a set of postscript files (readable with the HDSview local client) on the HDSware distribution media. These can be viewed with the ViewStation's HDSperx client, HDS view.

The *HDS ViewStation Owner's Manual* is for general users and focuses on setting up the ViewStation for the first time. It is shipped with each ViewStation.

This manual is arranged in general sections as follows:

- Section 1.0 - ViewStation features and operations
- Section 2.0 - ViewStation local client programs